


Torch exchange station TES

**Increase productivity
& flexibility**



In detail

System overview & technical data




Torch exchange station TES:
Front system overview

Home position, locking body down
with locking fork retracted

Locking body up, locking fork extended

Locking body up, locking fork retracted

Locking body down, locking fork extended



Torch exchange station TES:
Rear view of pneumatic connections

Pneumatic cylinder end position sensors

Torch exchange station TES. **Increased productivity & flexibility ...**


The torch exchange station TES can be used anywhere welding torches need to be exchanged quickly and reliably. The strengths of the system include a change of torch geometry or even preventive torch changes for servicing wear parts of a TIG welding torch ABITIG® WH or MIG/MAG WH welding torch.

Thanks to the modular system design, up to four TES units can be mated together. The exchange stations are controlled by a PLC or by integrating the TES module into a field bus system. This guarantees full control of the units status at any time. Integrated sensors help record the position of the changing movements and recognize the position of the welding torch for the exchanging process.

The torch exchanging movement is carried out by the welding robot. This allows freedom with respect to designing the welding cell and offers excellent flexibility in positioning the exchange stations in the welding cell – regardless of whether it is on a large gantry welding system in the heavy fabrication plant or in compact welding cells in mass production facilities.

In combination with the proven MIG/MAG WH welding torch necks, the integrated cutting of the wire electrodes ensures safe and secure torch exchanges, even if the wire electrode has melted to the contact tip of the welding torch due to poor arc starts, wire feed faults etc.

Unit torch exchange station



Key features and benefits:

- Simple and inexpensive solution for automatic torch exchanges
- Up to four exchange stations can be combined
- Can be used for TIG* and MIG/MAG applications
- Simple, durable, user-friendly design
- Low operating and maintenance costs
- Increased welding cell uptime
- Use of different torch angles possible for better part access


* Currently only without cold wire feed



In detail

System overview & technical data

Torch exchange station TES:
With TIG welding torches ABITIG® WH




Tungsten electrode wear has an impact on the quality of the TIG weld. To maintain a stable and strong weld quality, these electrodes need to be changed regularly to ensure consistent quality.

With the new torch exchange station TES by ABICOR BINZEL, the TIG welding torch ABITIG® WH can be exchanged reliably and quickly at precisely the right time, the output quantity can be improved and downtime reduced.

Torch exchange station TES:
With TIG welding torches ABITIG® WH

- Different torch geometries can be used
- System availability improved by automated torch exchange / electrode change
- Ensures quality welds

Torch exchange station TES:
With various MIG/MAG WH welding torch geometries



In the case of complex parts, various accessibility situations are normal for the robot welding torch. It often becomes necessary to use a welding torch neck of a different length, angle and output class to allow the welding process to continue.

The torch exchange station TES by ABICOR BINZEL is just the right solution in this case. The TES can accommodate up to four different MIG/MAG WH welding torches. The TES is the ideal system component for process-reliable, effective and automated MIG/MAG welding and ensures much lower downtimes for changing the welding torch geometry and/or amperage class, and also allows preventive changes or offline maintenance of the wear parts.

Torch exchange station TES:
With various MIG/MAG WH welding torch geometries

- Different torch geometries can be used
- System availability improved by automated torch exchange / offline consumable change
- Safe torch exchange by means of integrated wire cutter in the WH cable assembly

System integration

4-position changing station

Station Overview



Torch exchange station TES with mounting frame for MIG/MAG ROBO WH Torch

ABITIG® WH TIG station application available

Shown with four individual stations

Order

Description	Part-No.
Torch exchange station "TES" single module w.o pneumatic connection set	840.0377*
TES single unit installation valve cluster w/hoses	840.0395

* Part-No. 840.0377 does not include solenoid valve and connection cables. Please order 840.0395 separately for new installations.

Technical data:

Torch exchange station TES

Operating pressure:

- max. 116 psi/min. 87 psi

Pneumatic connection:

- Connection Ø 6 mm

Electrical connection:

Cable connections M12

4 outputs

- Proximity switch 24 V DC/
max. 200 mA
- Switch output pnp No

2 outputs

- Proximity switch 24 V DC/
max. 200 mA
- Switch output pnp No


2 inputs*

- 5/2 solenoid valves 24 V DC
- Power consumption 2.8 W

* Depending on the PN

Dimensions:

Torch exchange station TES





Binzel S.A. DE C.V.
Municipio Pabellon de Arteaga 102
Valle De Aguascalientes, 20358
San Francisco de los Romo, Ags.
Phone: +52 (499) 973.0133
Fax: +52 (499) 973.1388
Email: info@binzel.com.mx



ABICOR BINZEL USA Inc.
650 Medimmune Court, Suite 110
Frederick, MD 21703
Phone: 1.800.542.4867
Fax: 1.301.846.4497
Email: customerservice@abicorusa.com

www.binzel-abicor.com